




504 King Vehicle Counts at Bathurst/EB 600 to 700




504 King Capacity at Bathurst/EB 600 to 700



504 King Vehicle Counts at Bathurst/EB 700 to 800




504 King Capacity at Bathurst/EB 700 to 800




7-8 AM

504 King Vehicle Counts at Bathurst/EB 800 to 900




504 King Capacity at Bathurst/EB 800 to 900




8-9 AM

504 King Vehicle Counts at Bathurst/EB 900 to 1000



504 King Capacity at Bathurst/EB 900 to 1000



9-10 AM



504 King Total Capacity at Bathurst/EB from 600 to 1000

